

thinkTANK™ photo

Be Ready "Before The Moment"

Glass Taxi™

This convertible bag, which can be used as a small backpack or as a shoulder bag, holds large lenses or a camera system. Meets international airline carry on standards and can fit in the overhead or under the seat on an airplane.

How to Configure the Interior



SLR System: The product comes with dividers so that it can be configured for multiple scenarios. Experiment with the dividers to match the equipment you carry.



Removable Bottom Ring.: Depending on the size of your lens hood, you can use or remove the foam ring.



300mm 2.8 Lenses or Similar: Some larger lenses can be put into the Glass Taxi with the SLR attached, as shown here with a 300 2.8. The foam ring you see at the bottom of the lens hood is provided to securely fit the lens in the bottom of the bag and prevent wobble.



400mm 2.8 or 500mm 4 Lens: The Glass Taxi can hold a 400mm 2.8 lens or a 500mm 4 lens with the hoods reversed. Remove all of the dividers and use the foam security collar to attach the top of the lens to the inside of the bag. The leather cover that comes with the lens hood will also fit inside of the bag.

How to Attach/Remove the Pro Speed Belt™ or Steroid Speed Belt™ (not included with the product)



Attaching the Pro Modulus Speed Belt or Steroid Speed Belt:

You can slide the belt into the slot on the bottom back of the bag. This allows you to wear the Pro Speed Belt or Steroid Speed Belt with other Modulus components attached such as the Lens Changer 50, Trim Changer, etc.



Releasing the Pro Speed Belt while wearing the Glass Taxi:

This feature allows you to wear your Pro Speed Belt set up with your preferred configuration and to remove the backpack without taking off of the belt. This is accomplished with a Hook and Loop flap that holds the belt in position and wraps under the bag. To release the belt, grab under the bag and release the hook and loop (continue reading below).



Releasing the Pro Speed Belt while wearing the Glass Taxi:

After you have released the hook and loop, pull up on the backpack and the flap will slide behind the belt and detach. This expedites the process of setting up your gear quickly. Depending on what you are wearing, it is possible to put the backpack on and insert the flap behind the belt, then attach the hook and loop.

How to Attach a Monopod



There are two straps included that say “Monopod Strap.” Thread the strap under the webbing on the side of the bag, thread the buckle, and then tighten around the monopod in one or two positions.

How to Attach a Tripod



There are two straps included that say “Tripod Strap.” Thread the strap under the webbing on the side of the bag, thread the buckle, and then tighten around the Tripod in one or two positions.

How to Attach the Raincover



The elastic around the edges of the seam-sealed raincover allows you to simply pull it around the bag and secure it in the correct position. There are slots in the side of the raincover where the D rings are located to allow the shoulder strap to be reconnected.

How to Attach a Modulus™ Component



The “Rail” on the front of the bag can be used to attach other Modulus components. Simply use the hook and loop flap on the back of the Modulus component to wrap around the Rail on the Glass Taxi and secure it in position.

thinkTANK™ photo

Be Ready “Before The Moment”

www.ThinkTankPhoto.com
CustomerService@ThinkTankPhoto.com
866.55THINK (866.558.4465)